Translight Training Sheet (Illustrated)

This training sheet provides step-by-step illustrated guidance for installing a translight on a frame.

Follow all procedures exactly as shown.

1. Build an oversize frame (75mm clearance).
2. Attach top edge from centre outward.
3. Secure sides evenly to ladder beams.
4. Apply ratchet tension A↔B as diagram shows.
5. Install lower beam on cleats and attach bottom edge.
6. Confirm alignment, seam straightness, and even tension.

Reference Diagram

